



No.	PARTSNAME	No.	PARTSNAME	No.	PARTSNAME
1	Wrench	46	Spring for silence	71	High speed pinion gear
2	Handle knob	47	Anti-reverse ratchet	74	Spool spring washer
4	Handle knob screw	48	Set plate screws	75	Spool washer
7	T handle nail	49	Set plate	76	Pressure plate
9	Ball bearing	50	Plate support	77	Press spring
11	Handle arm	51	Anti-reverse dog	78	Drag plate
12	Handle knob screw	52	Set plate nail	79	Ball bearing
15	Buttonscrew	53	Ball bearing	80	Spool
20	Stopping slice	54	Close cover screws	81	Ball bearing
21	Handle bolt washer	55	Close cover	82	Alarm sound slice
23	Handle bolt	56	Drag tension knob	83	Alarm sound slice screw
25	Drive shaft washer	57	Sound nail spring	84	Sound spring pin
26	Ball bearing	58	Sound nail	85	Soundspring
27	Drive shaft washer	59	Fixed plate screws	86	Soundnailwasher
28	Drive shaft	60	Lever hub cover	87	"E" washer
30	Drive gear-high speed	61	"E" washer	88	Soundplate
37	Drive shaft screw	62	Drag control lever washer	89	Alarmadjustcoat
38	Limitedscrew	63	Dragcontrollever	90	Alarmadjustcoatwasher
39	Limitedbushing	64	Drag control lever ring	91	Alarmadjustcoatwasher
40	Pre-program plate washer	65	Side platescrews	92	Strikealertbutton
41	Pre-program plate	66	Right side plate	94	Reel foot
42	Pre-program key	67	Limited button	95	Reel foot screws
43	Pre-program screw	68	Limited button spring	97	Rod clamp
44	Ball bearing	69	Limited button cover	98	Fixed screws
45	Spring cover for silence	70	Fixed plate screw	99	Frame