



No.	PARTSNAME	No.	PARTSNAME	No.	PARTSNAME
1	Wrench	44	Ball bearing	71	High speed pinion gear
2	Handle knob	45	Spring cover for silence	74	Spool spring washer
4	Handle knob screw	46	Spring for silence	75	Spool washer
5	Handle shaft retainer	47	Anti-reverse ratchet	76	Pressure plate
6	Handle shaft washer	48	Set plate screws	77	Press spring
7	T handle nail	49	Set plate	78	Drag plate
8	Handle shaft coat	50	Plate support	79	Ball bearing
9	Ball bearing	51	Anti-reverse dog	80	Spool
10	Handle shaft coat washer	52	Set plate nail	81	Ball bearing
11	Handle arm	53	Ball bearing	82	Alarm sound slice
12	Handle knob screw	54	Close cover screws	83	Alarm sound slice screw
15	Buttonscrew	55	Close cover	84	Sound spring pin
20	Stopping slice	56	Drag tension knob	85	Soundspring
21	Handle bolt washer	57	Sound nail spring	86	Soundnailwasher
23	Handle bolt	58	Sound nail	87	"E" washer
25	Drive shaft washer	59	Fixed plate screws	88	Soundplate
26	Ball bearing	60	Lever hub cover	89	Alarmadjustcoat
27	Drive shaft washer	61	"E" washer	90	Alarmadjustcoatwasher
28	Drive shaft	62	Drag control lever washer	91	Alarmadjustcoatwasher
30	Drive gear-high speed	63	Dragcontrollever	92	Strikealerbutton
37	Drive shaft screw	64	Drag control lever ring	94	Reel foot
38	Limitedscrew	65	Sideplatescrews	95	Reel foot screws
39	Limitedbushing	66	Right side plate	97	Rod clamp
40	Pre-program plate washer	67	Limited button	98	Fixed screws
41	Pre-program plate	68	Limited button spring	99	Frame
42	Pre-program key	69	Limited button cover		
43	Pre-program screw	70	Fixed plate screw		