



| No. | PARTSNAME                | No. | PARTSNAME                 | No. | PARTSNAME                |
|-----|--------------------------|-----|---------------------------|-----|--------------------------|
| 1   | Wrench                   | 34  | Shaft insert spring       | 66  | Right side plate         |
| 2   | Handle knob              | 35  | Drive shaft spring        | 67  | Limited button           |
| 4   | Handle knob screw        | 36  | Friction washer           | 68  | Limited button spring    |
| 5   | Handle shaft retainer    | 37  | Drive shaft screw         | 69  | Limited button cover     |
| 6   | Handle shaft washer      | 38  | Limited screw             | 70  | Fixed plate screw        |
| 7   | T handle nail            | 39  | Limited bushing           | 71  | High speed pinion gear   |
| 8   | Handle shaft coat        | 40  | Pre-program plate washer  | 72  | Main shaft pin           |
| 9   | Ball bearing             | 41  | Pre-program plate         | 73  | Pinion gear              |
| 10  | Handle shaft coat washer | 42  | Pre-program key           | 74  | Spool spring washer      |
| 11  | Handle arm               | 43  | Pre-program screw         | 75  | Spool washer             |
| 12  | Handle knob screw        | 44  | Ball bearing              | 76  | Pressure plate           |
| 13  | Push button shaft        | 45  | Spring cover for silence  | 77  | Press spring             |
| 14  | Push button E washer     | 46  | Spring for silence        | 78  | Drag plate               |
| 15  | Button screw             | 47  | Anti-reverse ratchet      | 79  | Ball bearing             |
| 16  | Button basement          | 48  | Set plate screws          | 80  | Spool                    |
| 17  | Alarm lever knob         | 49  | Set plate                 | 81  | Ball bearing             |
| 18  | Push slice screw         | 50  | Plate support             | 82  | Alarm sound slice        |
| 19  | Push nail                | 51  | Anti-reverse dog          | 83  | Alarm sound slice screw  |
| 20  | Stopping slice           | 52  | Set plate nail            | 84  | Sound spring pin         |
| 21  | Handle bolt washer       | 53  | Ball bearing              | 85  | Sound spring             |
| 22  | Push slice               | 54  | Close cover screws        | 86  | Sound nail washer        |
| 23  | Handle bolt              | 55  | Close cover               | 87  | "E" washer               |
| 24  | Push spring              | 56  | Drag tension knob         | 88  | Sound plate              |
| 25  | Drive shaft washer       | 57  | Sound nail spring         | 89  | Alarm adjust coat        |
| 26  | Ball bearing             | 58  | Sound nail                | 90  | Alarm adjust coat washer |
| 27  | Drive shaft washer       | 59  | Fixed plate screws        | 91  | Alarm adjust coat washer |
| 28  | Drive shaft              | 60  | Lever hub cover           | 92  | Strike alert button      |
| 29  | Gear cross bar           | 61  | "E" washer                | 94  | Reel foot                |
| 30  | Drive gear-high speed    | 62  | Drag control lever washer | 95  | Reel foot screws         |
| 31  | Various speed washer     | 63  | Drag control lever        | 97  | Rod clamp                |
| 32  | Drive gear-low speed     | 64  | Drag control lever ring   | 98  | Fixed screws             |
| 33  | Slide coat               | 65  | Side plate screws         | 99  | Frame                    |